

# Manual Ratchet Threaders



## EXPOSED RATCHET THREADER SETS

All matched Threader/Sets include Die Heads, Ratchet Assembly, Ratchet Handle and Alloy Dies. All Threader Sets use same 12-R Dies in Die Head.

- Model 00-R: Capacity 1/8" - 1" without carrying case.
- Model 12-R: Capacity 1/8" - 2" with carrying case.

| Catalog No. | Model No. | Description | Die Heads Include |         | Weight  |        |
|-------------|-----------|-------------|-------------------|---------|---------|--------|
|             |           |             | in.               | mm      | lb.     | kg     |
| 36345       | 00-R      |             | 1/2 - 1           | 12 - 25 | 10      | 4.5    |
| 36355       |           |             | 3/8 - 1           | 10 - 25 | 1 1/4   | 5.1    |
| 36375       |           |             | 1/8 - 1           | 3 - 25  | 13 3/4  | 6.2    |
| 36480       | 12-R      | NPT         | 1/2 - 1 1/4       | 12 - 32 | 23 3/4  | 10.8   |
| 36475       |           |             | 1/2 - 2           | 12 - 50 | 34 3/4  | 15.8   |
| 36505       |           |             | 1/8 - 2           | 3 - 50  | 45 1/2  | 20.7   |
| 55207*      |           |             | 1/2 - 2           | 12 - 50 | 35 1/2  | 16.1   |
| 65175       | 00-R      |             | 1/2 - 1           | 12 - 25 | 10      | 4.5    |
| 65255       | 12-R      | BSPT        | 1/2 - 2           | 12 - 50 | 34 3/4  | 15.8   |
| 65285       |           |             | 1/8 - 2           | 3 - 50  | 45 1/2  | 20.7   |
| 36510       |           |             | NPSM              | 1/2 - 2 | 12 - 50 | 34 3/4 |

\*For plastic-coated pipe



## ENCLOSED RATCHET THREADER SET

- All matched Threader/Sets include Die Heads, Ratchet Assembly, Ratchet Handle and Alloy Dies. All Threader Sets use same 12-R Dies in Die Head.
- No 11-R capacity: 1/8" - 1 1/4".

| Catalog No. | Model No. | Description | Die Heads Include |       | Weight |     |
|-------------|-----------|-------------|-------------------|-------|--------|-----|
|             |           |             | in.               | mm    | lb.    | kg  |
| 36390       | 11-R      | NPT         | 1/2 - 1 1/4       | 12-32 | 16     | 7.3 |



## RATCHET & HANDLE ONLY

- Ratchet knob indicates forward and reverse.
- Die heads snap in from both sides and lock in place.

| Catalog No. | Model No.    | Description           | Type of Ratchet |
|-------------|--------------|-----------------------|-----------------|
| 38540       | 00-RB & 00-R |                       | Exposed         |
| 37777       | 11-R         |                       | Enclosed        |
| 38550       | 11-R         | Ratchet & Handle Only | Enclosed        |
| 30118       | 12-R         |                       | Exposed         |
| 38535       | 0-R          |                       | Exposed         |



See page 4.12