



no.	description	part no.	2003V	2090V
1	Back Flow Preventer S/A	33633-07		
2	Screw	33334-07		
3	Paddle Lever	33409-07		
4	Rubber Seal	33420-07		
5	Ventilator S/A	33492-07		
	Ventilator S/A	33490-07		
6	Vacuum Tube	33457-07		
7	Mounting Screws (4)	33253-07*		
8	Rubber Seal	33496-07		
9	Discharge Tube S/A	47054-07		
10	Mounting Elbow S/A	33501-07		
11	Flush Valve #6	47049-07**		

• NOT AVAILABLE

\*\*See page number 3-32 for components.  
 Note: For NON-VENTILATED components use items 1 through 4 and item 11. For water control parts see page 3-5 for 2003V and page 3-3 for 2090V