



Brantford™ and Arbor® with MotionSense™

MotionSense provides the convenience of having a kitchen faucet that can literally sense what you're trying to accomplish and respond to what you need, the moment you need it. That's because MotionSense activates flow based on simple hand movements. This convenient, hands-free control assists in accomplishing routine tasks with greater speed and efficiency. MotionSense is now available on faucets in our traditionally styled Brantford collection or with the tailored look of our transitionally styled Arbor collection.

*motion*sense™ Smart Sensing Zones

1. Pass your hand over the **Wave Sensor** at the top of the faucet spout. MotionSense will turn your faucet on and run water until you turn it off. Great for filling large pots and washing dishes.
2. The **Ready Sensor** detects when you place your hands or an object below the spout and supplies water only until you exit the sensor zone. That means you'll use water more wisely when you need to wash your hands or rinse a plate.
3. Use the **handle** at any time to turn on the faucet or adjust flow and temperature.



Brantford High-Arc Hands-Free Single-Handle Pulldown Faucet with MotionSense / 7185E *NEW!*

(Optional deckplate included)



CHOOSE YOUR FINISH

To order, combine the model number with one of these finish letter(s).
 Chrome **(C)**, Oil Rubbed Bronze **(ORB)**, Spot Resist™ Stainless **(SRS)**



Arbor High-Arc Hands-Free Single-Handle Pulldown Faucet with MotionSense / 7594E

(Optional deckplate included)



See page 9 for more information.



Featured on all pulldown faucets.
 See page 8 for more information.

Watch a video showcase for this collection. Scan here.



Download app at getscanlife.com.