

CATALOG NUMBER

**ECCS2**

**electricCenter**  
ACCESSORIES

**250 kcmil Collar Strap**  
Wire Range: #6 AWG - 250 kcmil

For use on "GB" type ground bars only

Same As:

■ CS2



---

**INSTALLATION INSTRUCTIONS**

---



**⚠ DANGER**

**Hazardous Voltage.**  
Will cause death, serious injury  
or substantial property damage.


Turn off power supplying this  
equipment before working inside.

**⚠ SAFETY INSTRUCTIONS**

**NOTE:** This instruction outlines the  
recommended installation procedure.

**Collar Strap:**

Wire Range: #6 AWG - 250 kcmil  
Tightening Torque: 250 lb.-ins.



1. Turn off and lock off the power supplying this equipment before working inside.
2. Loosen 3 screws on ground bar at desired location of collar strap.
3. Insert the feet of the collar strap into ground bar and tighten the screws in Step 2 to 45 lb.-ins.

4810402 Rev.A