Catalog Number LC3040L1200 LC3040L1200CU Model

Enclosure Type 1

Indoor Load Center

RATINGS: 200A MAXIMUM - SEE MAIN BREAKER RATING IF USED BACK-FED BREAKER REQUIRES HOLD-DOWN KIT MBR2M. 120/240 V~. 60 HZ. 1Ø 3W 208Y/120 V~. 60 HZ. 1Ø 3W

SUITABLE FOR USE AS SERVICE EQUIPMENT WHEN MAIN BREAKER IS

INSTALLED. WHEN USED AS SERVICE EQUIPMENT, APPLY "SERVICE DISCONNECT" LABEL TO FRONT NEXT TO MAIN BREAKER HANDLE.

WHEN USED AS SERVICE EQUIPMENT, UNUSED NEUTRAL BAR TERMINALS MAY BE USED TO TERMINATE EQUIPMENT GROUNDING WIRES IN THE COMBINATIONS INDICATED FOR EQUIPMENT GROUND BAR TERMINALS.

TO BOND NEUTRAL TO ENCLOSURE: (1) REMOVE SCREW SECURING BOND STRAP. (2) INSERT ROUND END OF BOND STRAP INTO LARGE HOLE OF NEUTRAL IN LINE WITH BOND STRAP MOUNTING HOLE. (3) REASSEMBLE BOND STRAP TO ENCLOSURE WITH SCREW PROVIDED. TIGHTEN TO 25 LB-IN. (4) TIGHTEN CONNECTOR SET SCREW ON ROUND END OF BOND STRAP TO 45 LB-IN. WITH NEUTRAL BONDED, LEFT BAR BECOMES SPLIT NEUTRAL.

SUM OF MH-T BREAKER RATING IS NOT TO EXCEED 110 AMPS PER BRANCH CIRCUIT BUS STAB.

TO RESET BREAKERS WITH TRIPPED HANDLE POSITION BETWEEN "ON" AND "OFF", MOVE HANDLE TO "OFF" THEN TO "ON".

REMOVE TWISTOUTS FROM TRIM ONLY WHERE BREAKERS WILL BE INSTALLED. ALL OPENINGS MUST BE FILLED WITH BREAKERS OR FILLER PLATES. USE TWO LX100FP FILLER PLATES TO FILL 150-225A MAIN BREAKER OPENING.

THIS LOAD CENTER IS INVERTIBLE FOR BOTTOM FEED APPLICATIONS.

Murray Electrical Products

Siemens Energy & Automation, Inc. Alpharetta, Georgia U.S.A.



IMPORTANT: DO NOT ALLOW PETROLEUM BASED (HYDROCARBON) SPRAYS, CHEMICALS, SOLVENTS OR ANY PAINT TO CONTACT INTERIOR COMPONENTS. PETROLEUM BASED CHEMICALS CAN CAUSE DEGRADATION OF ELECTRICAL INSULATING MATERIALS.

DANGER

Hazardous Voltage. Will cause death, serious injury or substantial property damage.

Turn off power supplying this equipment before working inside.



▲ PELIGRO

Voltaje peligroso. Causará la muerte, lesiones graves o daño substancial a la propiedad.

Desconecte el suministro de energía a este equipo antes de trabajar en su interior.

SHORT CIRCUIT CURRENT RATING

THIS PANELBOARD HAS A MAXIMUM SHORT CIRCUIT CURRENT RATING OF 100,000 AMPS RMS SYMMETRICAL, 120/240V~. THE ACTUAL RATING IS DEPENDENT ON THE BRANCH BREAKERS INSTALLED IN THIS PANELBOARD AND THE MAIN/FEEDER BREAKER, IF ANY, INSTALLED AHEAD OF THIS PANELBOARD. THE CORRECT MAIN BREAKER/FEEDER/MAIN BREAKER/PANELBOARD MAIN BREAKER/BRANCH BREAKER SERIES COMBINATIONS TO BE USED ARE LISTED IN THE TABULATION BELOW. ANY CIRCUIT BREAKER INSTALLED, REPLACED, OR ADDED IN THIS PANELBOARD MUST BE MANUFACTURED BY SIEMENS (MURRAY BRAND) AND MUST BE OF THE CORRECT TYPE AS INDICATED IN THE TABULATION BELOW. USE OF OTHER CIRCUIT BREAKERS IN THIS EQUIPMENT WILL VOID THE WARRANTY.

	MAIN BREAKER	FEEDER/MAIN BREAKER	PANELBOARD MAIN‡	BRANCH BREAKER	THEN THE MAX. SHORT CIRCUIT	
	WHEN THE MAIN PROTECTING THE SYSTEM IS A	AND THE BREAKER PROTECTING THIS PANELBOARD IS A TYPE	AND THE INSTALLED MAIN BREAKER IN THIS PANELBOARD IS A TYPE	AND THE BRANCH BREAKERS INSTALLED ARE TYPE	CURRENT RATING IN RMS SYMMETRICAL AMPS, 120/240 V~ IS	
[NONE USED	MD-T, MD-TR		MP-T, MG, MH-T, MP-HT,	iΤ΄,	Ų
ŀ	NONE USED OR SIEMENS BREAKER TYPES JXD2(-A), JD6(-A), JXD6(-A), HJD6(-A), HJXD6(-A), LD6(-A), LD6(-A), HLD6(-A), HLD6(-A), HLXD6(-A), MD6, MXD6, HMD6, HMXD6, ND6, NXD6, HND6,	MPP-T, MQ	NONE USED, M2 OR MP-T	MP-MT, MP-GT, MP-HGT, MP-ET, MP-HET, MP-AT, MP-HAT, MD-TR, MD-HTR, MD-MTR		5
	HNXD6, OR CLASS J, T, R OR L FUSES	NONE USED	M2 OR MP-HT	MP-T, MH-T, MP-HT, MP-MT,	22,000	
[NONE USED	MD-HT, MD-HTR	NONE USED	MP-GT, MP-HGT, MP-ET, MP-HET, MP-AT, MP-HAT.		
lì	NONE USED OR SIEMENS BREAKER TYPES JXD2(-A), JD6(-A), JXD6(-A), HJD6(-A), HJXD6(-A), LD6(-A), LXD6(-A), HLD6(-A), HLXD6(-A), MD6, MXD6, HMD6, HMXD6, ND6, NXD6, HND6, HNXD6, OR CLASS J, T, R OR L FUSES	MPP-HT, MQH	OR M2	MD-TR, MD-HTR, MD-MTF		
		NONE USED	NONE USED	MP-HT, MP-HGT, MP-HET, MP-HAT, MD-HTR		
		MQL	NONE USED	MP-T, MP-HT, MP-MT, MD-TR, MD-HTR, MD-MTR	42,000	 4
	SIEMENS BREAKER TYPES JXD2(-A), JD6(-A), JXD6(-A), HJD6(-A), HJXD6(-A), LD6(-A), LXD6(-A), HLD6(-A), HLXD6(-A), MD6, MXD6, HMD6, HMXD6, ND6, NXD6, HND6, HNXD6, OR CLASS J, T, R OR L FUSES	MD-T, MD-HT, MD-MT, MD-TR, MD-HTR, MD-MTR, MPP-MT	NONE USED, MP-GT, MP-HGT, M M2 OR MP-MT MP-HET, MP-AT, MI	MP-T, MH-T, MP-HT, MP-MT, MP-GT, MP-HGT, MP-ET, MP-HET, MP-AT, MP-HAT,	65,000	
1	NONE USED	MPP-MT, MD-MT, MD-MTR	1	MD-TR, MD-HTR, MD-MTR		ı
- 1	NONE USED	NONE USED	NONE USED	MP-MT, MD-MTR]	۱–
- 1	NONE USED OR SIEMENS BREAKER TYPES HJD6(-A), HJXD6(-A), HLD6(-A), HLXD6(-A), HMD6, HMXD6, HND6, HNXD6, OR CLASS T FUSES	MPP-PT	NONE USED OR M2	MP-T, MH-T, MP-HT, MP-MT, MP-GT, MP-HGT, MP-ET, MP-HET, MP-AT, MP-HAT	100,000 凝	
] ۸	CLASS L FUSES	HQJ2H	NONE USED	MP-HET, MP-AT, MP-HAT	Ę.	

‡ THIS PANELBOARD IS EITHER A MAIN LUG DEVICE THAT MAY BE CONVERTED TO MIN BERAKER WITH THE ADDITION OF FIELD INSTALLED MAIN BREAKER KIT OR A MAIN BREAKER KIT OR A MAIN SECONVERTED TO MAIN LUG WITH THE ADDITION OF MAIN LUGS SEE ACCESSORY TABLE FOR CATALOG NUMBERS OF APPROPRIATE KITS.

USE COPPER OR ALUMINUM 60°/75°C WIRE SEE BREAKER MARKINGS FOR WIRE SIZE AND TORQUE REQUIREMENTS.

TERMINALS	WIRE	TORQUE			
A, B	300 kcmil-4 AWG	275 LB-IN			
N	300 kcmil-4 AWG	250 LB-IN			
G	2/0 - 6 AWG	90 LB-IN			
NEUTRAL AN	UTRAL AND EQPT GROUND BAR				
SMALL TERMINALS LARGE TERMINALS	10 - 14 AWG 8 AWG 6 AWG 10 - 14 AWG 8 AWG 1/0 - 6 AWG	20 LB-IN 25 LB-IN 35 LB-IN 35 LB-IN 40 LB-IN 45 LB-IN			
LX081M NEUTRAL LUG KIT	2/0 - 6 AWG	50 LB-IN			
MAIN LUG/MAIN B CONNECTION (1/	45 LB-IN				

EQUIPMENT GROUND BAR

TERMINALS ARE SUITABLE FOR THE FOLLOWING WIRE COMBINATIONS: SMALL TERMINALS: ONE 14 TO 6 AWG CU: ONE 12 TO 6 AWG AL: TWO 14 AWG CU; TWO 12 AWG CU; TWO 12 AWG AL SOLID WIRES.

LARGE TERMINALS: ONE 14 TO 2 AWG CU: ONE 12 TO 2 AWG AL: TWO OR THREE 14 AWG CU; TWO OR THREE 12 AWG CU OR AL; TWO 10 AWG CU; TWO OR THREE 10 AWG AL: THREE 10 AWG CU SOLID WHEN TORQUED TO 50 LB-IN: THREE 10 AWG CU STRANDED

ACCESSORIES		
DESCRIPTION	CAT. NO.	
DOOR LOCK	QFL2M	
FILLER PLATE, 1"	LX100FP	
BREAKER HOLD-DOWN	MBR2M	
GROUND BAR KITS - USE "LX" SERIES		

MAIN LUG / MAIN BREAKER KITS			
USE APPROPRIATE KIT FROM CHART BELOW TO CONVERT PANEL.			
DESCRIPTION	CAT. NO.		
150 AMP MAIN BREAKER	MBK150M		
200 AMP MAIN BREAKER	MBK200M		
150-225 AMP MAIN LUG	MLK225M		



